

# Heat Transfer Application Instructions

Transfer Type

**NEON**

**Heat Press Settings:**  
Temperature 368° - 370°

Pressure 70 lbs • Firm Pressure • 7 - 9 on Auto Clam Hotronix

**PREHEAT PLATEN:** Prior to beginning, press empty pad for **3** cycles of **15** seconds.  
*Failure to preheat pad will cause insufficient heat and will damage first 3 transfers.*

**STEP #1: LOAD GARMENT:**

Prior to pressing, open the bottom of the garment and slide it over the platen. Pressing one side of the item at a time will eliminate ghost images/bleed through. **WARNING!** If garment is laid on top of platen be sure to check for bleed through after pressing first garment.

**STEP #2: PRE-PRESS GARMENT:**

Press garment (with no transfer) for **3-5** seconds to remove moisture and wrinkles.

**STEP #3: POSITION TRANSFER:**

Place transfer in desired location, ink side down.  
Do not place transfer on wrinkles, seams or creases in garment.

**STEP #4: PRESS TRANSFER:**

Close heat press and press for **10** seconds at 368°.

→ **If Backed in White - Press at 360° for 8 sec.**

**STEP #5: PEEL TRANSFER:**

Open heat press, and peel transfer with a smooth steady motion.

☆ **TROUBLE SHOOTING TIPS** ☆

**PROBLEM:**

- o Transfer NOT splitting evenly onto garment

**SOLUTION:**

- o Increase Pressure
- o Increase Temperature
- o Peel Transfer *Immediately* after opening press
- o Verify Platen has been pre-heated

Washing  
Instructions on back

# Heat Transfer Application Instructions

Transfer Type

**NEON**

☆ **WASHING INSTRUCTIONS** ☆



Machine Wash, Cold  
Turn garment inside out



Do NOT bleach



Tumble Dry, Low Heat



Do NOT iron

See our design  
catalog on-line at  
www.versatranz.com