



14777 Keel St. Plymouth, MI 48170
Phone: 888.414.7604
Fax: 734.414.7607
www.versatranz.com
artwork@versatranz.com

Heat Transfer Application Instructions

Transfer Type  **VERSA COLOR™** NOT ON WHITE

Heat Press Settings:
Temperature 350°

Pressure 55-70 lbs • Medium-Firm Pressure • 6-9 on Auto Clam Hotronix

PREHEAT PLATEN: Prior to beginning, press empty pad for 3 cycles of 15 seconds.
Failure to preheat pad will cause insufficient heat and will damage first 3 transfers.

STEP #1: LOAD GARMENT:

Prior to pressing, open the bottom of the garment and slide it over the platen. Pressing one side of the item at a time will eliminate ghost images/bleed through. **WARNING!** If garment is laid on top of platen be sure to check for bleed through after pressing first garment.

STEP #2: PRE-PRESS GARMENT:

Press garment (with no transfer) for 3-5 seconds to remove moisture and wrinkles.

STEP #3: POSITION TRANSFER:

Place transfer in desired location, ink side down.
DO NOT cover transfer with Teflon sheet.
Do not place transfer on wrinkles, seams or creases in garment.

STEP #4: PRESS TRANSFER:

Close heat press and press for 4-6 seconds at 350°.

STEP #5: PEEL TRANSFER:

Open heat press, and peel transfer with a smooth steady motion.

☆ TROUBLE SHOOTING TIPS ☆

PROBLEM:

- o Transfer NOT splitting evenly onto garment

SOLUTION:

- o Increase Pressure
- o Increase Temperature Slightly
- o Peel Transfer *Immediately* after opening press
- o Verify Platen has been pre-heated
- o Increase Time

*Washing
Instructions on back*



14777 Keel St. Plymouth, MI 48170
Phone: 888.414.7604
Fax: 734.414.7607
www.versatranz.com
artwork@versatranz.com

Heat Transfer Application Instructions

Transfer Type  **VERSA COLOR™** NOT ON WHITE

☆ WASHING INSTRUCTIONS ☆



Machine Wash, Cold
Turn garment inside out



Do NOT bleach



Tumble Dry, Low Heat



Do NOT iron

*See our design
catalog on-line at
www.versatranz.com*