

Heat Transfer Application Instructions

Transfer Type

Wild Fashion

Heat Press Settings:
Temperature 325° - 340°

Pressure 60 lbs • Firm Pressure • 7 - 9 on Auto Clam Hotronix

PREHEAT PLATEN: Prior to beginning, press empty pad for 3 cycles of 15 seconds.
Failure to preheat pad will cause insufficient heat and will damage first 3 transfers.

STEP #1: CUT AND WEED:

All Designs must be cut in reverse. Weed away excess material.

STEP #2: LOAD GARMENT:

Prior to pressing, open the bottom of the garment and slide it over the platen. Pressing one side of the item at a time will eliminate ghost images/bleed through. **WARNING!** If garment is laid on top of platen be sure to check for bleed through after pressing first garment.

STEP #3: PRE-PRESS GARMENT:

Press garment (with no transfer) for 4 seconds to remove moisture and wrinkles.

STEP #4: POSITION TRANSFER:

Position transfer on garment in desired location with the carrying sheet side up and the design facing down.

Place Teflon sheet or silicone release sheet over design.
Do not place transfer on wrinkles, seams or creases in garment.

STEP #5: PRESS TRANSFER:

Close heat press and press for 12-15 seconds at 325° - 340° with firm pressure.

STEP #6: COOL & PEEL TRANSFER:

Open heat press, wipe transfer and Teflon with dry rag/heat eraser for 20-30 seconds. Remove Teflon sheet and peel with smooth steady motion.
Transfer **CAN NOT** be reused.

Washing
Instructions on back

Heat Transfer Application Instructions

Transfer Type

Wild Fashion

☆ **TROUBLE SHOOTING TIPS** ☆

PROBLEM:

o Transfer NOT splitting evenly onto garment

SOLUTION:

- o Increase Pressure
- o Increase Temperature
- o Let transfer cool *completely* before peeling
- o Verify Platen has been pre-heated

☆ **WASHING INSTRUCTIONS** ☆



Machine Wash, Cold
Turn garment inside out



Do NOT bleach



Tumble Dry, Low Heat



Do NOT iron

See our design
catalog on-line at
www.versatranz.com